

ICW-300V – SEBZE YIKAMA

MONTAJ ÖNCESİ SON KULLANICI TARAFINDAN YAPILMASI GEREKENLER

ÖNEMLİ: Yetkili servis teknisyenini çağırmadan önce, lütfen aşağıdakilerin tam ve eksiz yapılmış olduğuna dikkat edin. Aşağıdakilerden herhangi birinin eksik olmasından kaynaklanacak bir aksaklık nedeniyle montaj yapılamaz ise yetkili servisce tarafınızdan ücret talep edilecektir.

Gerekli su basıncı	2-4 Bar 8-10 lt/dakika
Su sertliği (max.) / iletkenlik (max.)	12°dF / 1000 µS/ cm (25°C)
Elektrik Bağlantısı	380V/3N/50-60Hz
Kablo kesiti	5x2,5 mm ² (R,S,T,Nötr,Toprak)
Sigorta	16A Trifaze Sigorta (Otomat) / 25A - 30mA Kaçak Akım Sigortası
Su girişi	¾" (Çamaşır Makinesi Musluğu)

ÖNEMLİ UYARILAR!!!

- *Sigorta girişinde kullanılan kablo antigron olmalıdır.
- *Cihazın bağlanacağı yerde mutlaka toprak hattı bulunmalıdır.
- * Pis su gideri zemin seviyesinde makinenin max 100 cm uzağında olmalıdır.
- * Su girişi max 100 cm uzağında olmalı ve su basıncı 2 Bar'den az ise basınç pompası kullanılmalıdır.
- * Su sertliği 10°dF den ve iletkenlik 800 µS/ cm'ten fazla ise su yumuşatıcısı kullanınız. **Kireçten ve iletkenlikten meydana gelecek arızalar garanti kapsamına girmez !**



MAKİNEİNİZİ KULLANMADAN ÖNCE KULLANMA KILAVUZUNU MUTLAKA OKUYUN!

ICW-300V – VEGETABLE WASHING MACHINE

PRE-INSALLATTION RESPONSIBILITIES BY END-USER

IMPORTANT! : Before calling the authorized service technician, please note that the following made full and seamless. Due to a glitch/error caused by the installation will be made if any of the following missing will be charged by your qualified service.

Water Preessure	2-4 Bar
Water hardness (max.) / Conductivity (max.)	12°dF / 1000 µS/ cm (25°C)
Electric Connection	380V/3N/50-60Hz
Cable	5x2,5 mm ² (R,S,T, Neutral, Ground)
Fuse	16A Three-phase (auto) / 25A - 30mA Residual-current relay
Water Inlet	¾"

IMPORTANT WARNINGS!!!

- *The cable used at the fuse inlet must be antigron.
 - *There must be a ground line at the place where the device will be connected.
 - * Waste water drain should be at ground level, at a maximum distance of 100 cm from the machine.
 - * The water inlet should be at a distance of maximum 100 cm and if the water pressure is less than 2 Bar, a pressure pump should be used.
 - * If the water hardness is more than 10°dF and the conductivity is more than 800 µS/cm, use a water softener.
- Defects caused by lime and conductivity are not covered by the warranty!



PLEASE READ THE USER'S MANUAL BEFORE USING YOUR MACHINE!.