

# ICW-1700 KONVEYÖR TİPİ BULAŞIK YIKAMA MAKİNESİ

## MONTAJ ÖNCESİ SON KULLANICI TARAFINDAN YAPILMASI GEREKENLER

**ÖNEMLİ:** Yetkili servis teknisyenini çağırmadan önce, lütfen aşağıdakilerin tam ve eksiz yapılmış olduğuna dikkat edin. Aşağıdakilerden herhangi birinin eksik olmasından kaynaklanacak bir aksaklık nedeniyle montaj yapılamaz ise yetkili servisce tarafınızdan ücret talep edilecektir.

Gerekli su basıncı	2-4 Bar 8/10 lt/dakika
Su sertliği (max.) / iletkenlik (max.)	10°dF / 800 µS/ cm (25°C)
Elektrik Bağlantısı	380V/3N/50-60Hz
Kablo kesiti	5x10 mm <sup>2</sup> (R,S,T,Nötr,Toprak)
Sigorta	63A Trifaze (otomat) - 80A-30mA Kaçak akım sigortası
Su girişi	¾" (çamaşır makinesi musluğu)
Pis su gideri	Ø50 mm

### ÖNEMLİ UYARILAR:

- \*Sigorta girişinde kullanılan kablo **antigron** olmalıdır.
- \*Cihazın bağlanacağı yerde mutlaka toprak hattı bulunmalıdır.
- \* Pis su gideri zemin seviyesinde makinenin max 100 cm uzağında olmalıdır.
- \* Su girişi max 100 cm uzağında olmalı ve su basıncı 2 Bar'den az ise basınç pompası kullanılmalıdır.
- \* Su sertliği 10°dF den ve iletkenlik 800 µS/ cm'ten fazla ise su yumuşatıcısı kullanınız. **Kireçten ve iletkenlikten meydana gelecek arızalar garanti kapsamına girmez !**
- \* Makineye kadar elektrik ve su tesisatının çekilmesi müşterinin sorumluluğundadır. Elektrik tesisatında duvara priz konmayacaktır.Cihazın ihtiyacını karşılayacak elektrik tesisatı ve otomat sigorta grubu yerden 180 cm yukarıda bulunmalı ve makinenin sağ yanında olmalıdır. (sol girişli makine için)



**MAKİNEİNİZİ KULLANMADAN ÖNCE KULLANMA KILAVUZUNU MUTLAKA OKUYUN! DETERJAN POMPASI REKOR BAĞLANTI DELİĞİ MAKİNEİNİN ARKA SACININ ARKASINDA İŞARETLENMİŞTİR LÜTFEN DİKKAT EDİNİZ.**

# ICW-1700 CONVEYOR TYPE DISHWASHER

## PRE-INSALLATTION RESPONSIBILITIES BY END-USER

**IMPORTANT!** : Before calling the authorized service technician, please note that the following made full and seamless. Due to a glitch/error caused by the installation will be made if any of the following missing will be charged by your qualified service.

<b>WATER PRESSURE NEEDED</b>	2-4 Bar 8/10 lt/min
<b>WATER HARDNESS (max.) / CONDUCTIVITY (max.)</b>	10°dF / 800 µS/ cm (25°C)
<b>ELECTRIC CONNECTIONS</b>	380V/3N/50-60Hz
<b>CABLE</b>	5x10 mm2 (R,S,T,Neutral,Ground)
<b>FUSE</b>	63A Three-phase (auto) - 80A-30mA Residual-current relay
<b>WATER INLET</b>	¾"
<b>DIRTY WATER OUTLET</b>	Ø50 mm

### WARNINGS !!!

- \*The cable used at the fuse input should be **antigrön**.
- \*There must be a ground line where the device is to be connected.
- \* The machine must be in the dirty water goes away ground level 100 cm max.
- \* Water inlet max should be 100 cm long and the water pressure is less than 2 bar pressure pump to be used.
- \* Water hardness and conductivity from 12 ° dF 1000 S / cm more than the use of water softeners. **Hardness and conductivity of failures occur not covered by the warranty!**
- \* With drawal of the machine until power and water supplies is the customer's responsibility. Electrical installations will be installed in the wall outlet. Electrical panel to meet the needs of the device and vending insurance group must be found above 180 cm from the ground and not on the machine. (k automat fuse)



**PLEASE READ THE USER'S MANUAL BEFORE USING YOUR MACHINE!. THE DETERGENT PUMP COUPLING CONNECTION HOLE IS MARKED BEHIND THE REAR SHEET OF THE MACHINE.**